

List of remote control codes
Liste des codes de commande
Liste der Fernbedienungs-codes
Lista över fjärrstyrningskoder
Elenco dei codici di telecomando
Lista de códigos de mando a distancia

TV	
A.R. Systems	0320
Acme	0342
Acura	0323, 0343
ADC	0337
Admiral	0054, 0178, 0336, 0337, 0339, 0346, 0347
Advent	0158
Adventura	0057
Adyson	0277, 0282, 0342
Agashi	0277, 0282
Agazi	0337
Aiko	0277, 0282, 0320, 0323, 0342, 0343
Aim	0320
Aiwa	0078, 0379
Akai	0050, 0055, 0109, 0159, 0181, 0277, 0282, 0320, 0323, 0340, 0343, 0349, 0350
Akiba	0320, 0340
Akura	0320, 0323, 0337, 0340
Alaron	0277
Alba	0161, 0277, 0320, 0323, 0340, 0342, 0343, 0344, 0349, 0351, 0372, 0382
Albatron	0140
Alcyon	0171
Alleron	0059
Allorgan	0282
Allstar	0320, 0350
America Action	0179
AMOi	0276
Amplivision	0161, 0282, 0321, 0342
Amstrad	0320, 0323, 0337, 0340, 0343
Amtron	0058
Anam	0179, 0343
Anam National	0052, 0058
Anglo	0323, 0343
Anitech	0171, 0320, 0323, 0337, 0343
Ansonic	0161, 0168, 0320, 0323, 0341, 0343
AOC	0008, 0026, 0050, 0053
Apex	0039, 0111, 0217
Arcam	0277, 0282
Arcam Delta	0342
Aristona	0320, 0349, 0350
Arthur Martin	0321
ASA	0339, 0347
Asberg	0171, 0320, 0350
Astra	0343
Asuka	0277, 0282, 0337, 0340, 0342
Atlantic	0277, 0320, 0342, 0349, 0350
Atori	0323, 0343
Auchan	0321
Audiosonic	0161, 0282, 0320, 0340, 0342, 0343, 0349, 0350
AudioTon	0161, 0282, 0342
Audiovox	0058, 0179, 0194
Ausind	0171
Autovox	0171, 0282, 0337, 0339, 0342
Aventura	0051
Awa	0277, 0282
Axion	0156
Baird	0282
Bang & Olufsen	0180, 0339
Basic Line	0282, 0320, 0323, 0340, 0343, 0350
Bastide	0282, 0342

Lijst met afstandsbedieningscodes
Liste over fjernbetjeningskoder
Liste over fjernkontrollkoder
Список кодов дистанционного управления
遥控器代码列表
리모콘코드목록

Baur	0320, 0349	Cathay	0320, 0349, 0350
Bazin	0282	CCE	0183, 0282
Beko	0161, 0269, 0294, 0302, 0311, 0320, 0328, 0351	Celebrity	0055, 0107
Belcor	0008	Celera	0039
Bell & Howell	0019, 0054	Centurion	0320, 0349, 0350
Benq	0097, 0242, 0361	Century	0339
Beon	0320, 0349, 0350	CGE	0161, 0171
Best	0161	Changhong	0039
Bestar	0161, 0320, 0350	Chimei	0273
Binatone	0282, 0342	Cimline	0323, 0343
Blue Sky	0320, 0340	Citizen	0007, 0008, 0026, 0050, 0058
Blue Star	0348	City	0323, 0343
Boots	0282, 0342	Clarion	0179
BPL	0320, 0348	Clarivox	0349
Bradford	0058, 0179	Clatronic	0161, 0171, 0282, 0320, 0323, 0337, 0340, 0342, 0343, 0350, 0351
Brandt	0322, 0345	CMS	0277
Brilliant	0182	CMS Hightec	0282
Brinkmann	0320	Coby	0197
Brionvega	0320, 0339, 0349, 0350	Colortyme	0008, 0026
Britannia	0277, 0282, 0342	Commercial Solutions	0021
Brockwood	0008	Concerto	0008, 0026
Broksonic	0109, 0179	Concorde	0323, 0343
Bruns	0339	Condor	0161, 0277, 0320, 0323, 0342, 0350, 0351
BTC	0340	Contec	0179, 0277, 0323, 0342, 0343, 0344
Bush	0269, 0282, 0283, 0304, 0320, 0323, 0328, 0332, 0340, 0343, 0344, 0346, 0348, 0349, 0350, 0372, 0382, 0463, 0470, 0472	Contec/Cony	0012, 0058
Candle	0008, 0026, 0050, 0057	Continental Edison	0345
Capsonic	0337	Cosmel	0323, 0343
Carena	0320	Craig	0058, 0179
Carnivale	0050	Crosley	0010, 0037, 0171, 0339
Carrefour	0344		
Carver	0010		
Cascade	0320, 0323, 0343		
Casio	0367		

Crown	0058, 0161, 0171, 0179, 0320, 0323, 0343, 0349, 0350, 0351	Elcit	0339	Frontech	0282, 0323, 0337, 0343, 0346, 0347	Grunpy	0058, 0059, 0179
CS Electronics	0277, 0340, 0342	Electa	0348	Fujitsu	0059, 0069, 0074, 0075, 0282	Haier	0157, 0233
CTC Clatronic	0341	ELECTRO TECH	0343	Fujitsu General	0282	Halifax	0277, 0282, 0337, 0342
CTX	0205	Electroband	0055, 0107	Fujitsu Siemens	0504, 0505, 0507, 0510, 0511	Hallmark	0008, 0026, 0031
Curtis Mathes	0007, 0008, 0010, 0019, 0021, 0026, 0049, 0050, 0178	Electrograph	0176	Funai	0051, 0058, 0059, 0112, 0113, 0115, 0118, 0119, 0179, 0337	Hampton	0277, 0282, 0342
CXC	0058, 0179	Electrohome	0008, 0026, 0052, 0055	Futuretech	0058, 0179	Hanseatic	0161, 0168, 0282, 0320, 0323, 0342, 0343, 0344, 0349, 0350
Cybertron	0340	Element	0230	Galaxi	0320, 0351	Hantarex	0320, 0323, 0343
Cytron	0152	Elin	0277, 0320, 0323, 0342, 0349, 0350	Galaxis	0161, 0320	Hantor	0320
Daewoo	0007, 0008, 0026, 0037, 0053, 0167, 0266, 0275, 0277, 0282, 0315, 0320, 0323, 0331, 0335, 0342, 0343, 0350, 0381, 0465	Elite	0320, 0340, 0350	Gateway	0176, 0177, 0241	Harman/Kardon	0010
Dainichi	0277, 0340	Elman	0341	GBC	0323, 0343, 0344	Harvard	0058, 0179
Dansai	0277, 0282, 0320, 0337, 0349, 0350	Elta	0277, 0323, 0343	GE	0008, 0021, 0023, 0026, 0027, 0031, 0034, 0049, 0052, 0056, 0209	Harwood	0320, 0323
Dantax	0161, 0349	Emerson	0000, 0007, 0008, 0012, 0013, 0019, 0026, 0031, 0037, 0051, 0058, 0059, 0161, 0179, 0320, 0339	Geant Casino	0321	Havermy	0178
Dawa	0320	Emprex	0154	GEC	0282, 0320, 0342, 0347, 0349, 0350	HCM	0282, 0320, 0323, 0337, 0342, 0343, 0348
Daytron	0007, 0008, 0026, 0323, 0343	Envision	0008, 0026, 0050	Geloso	0323, 0343, 0346	Hema	0282, 0323
De Graaf	0346	Epson	0155, 0206, 0359	General Technic	0323, 0343	Hewlett Packard	0192
Decca	0282, 0320, 0342, 0349, 0350	Erres	0320, 0349, 0350	Genexxa	0320, 0340, 0347, 0350	Higashi	0277
Dell	0145, 0245	ESA	0051	GFM	0128, 0227	HiLine	0320
Denver	0358, 0362	ESC	0282	Giant	0282	Hinari	0320, 0323, 0340, 0343, 0344, 0349, 0350
Desmet	0320, 0349, 0350	Etron	0343	Gibraltar	0008, 0030, 0050, 0062	Hisawa	0321, 0340, 0348
Diamant	0320	Eurofeel	0282	GoldHand	0277	Hisense	0247
Diamond	0277	Euro-Feel	0337	Goldline	0320	Hitachi	0008, 0012, 0026, 0066, 0084, 0092, 0093, 0120, 0172, 0173, 0255, 0270, 0271, 0282, 0320, 0335, 0338, 0342, 0344, 0346, 0347, 0365, 0382, 0448, 0456, 0467, 0482
DiamondVision	0135, 0143	Euroline	0349	GoldStar	0007, 0008, 0012, 0026, 0031, 0050, 0053, 0161, 0277, 0282, 0320, 0323, 0342, 0343, 0346, 0349, 0350	Hornlyphon	0320, 0350
Dimensia	0049	Euroman	0161, 0277, 0282	Goodmans	0246, 0272, 0282, 0320, 0323, 0337, 0343, 0344, 0349, 0350, 0462, 0473, 0477	Hoshai	0340
Disney	0219	Euromann	0320, 0337, 0342, 0350	Gorenje	0161, 0351	Huanyu	0277, 0342
Dixi	0282, 0320, 0323, 0343, 0349, 0350	Europhon	0277, 0282, 0320, 0341, 0342, 0350	GPX	0129	Hygashi	0277, 0282, 0342
Dream Vision	0461, 0498	Expert	0321	Gradiente	0240	Hyper	0277, 0282, 0323, 0342, 0343
DTS	0323, 0343	Exquisit	0320	Graetz	0347	Hypson	0282, 0320, 0321, 0337, 0342, 0348, 0349, 0350
Dual	0282, 0320, 0342	Fenner	0323, 0343	Granada	0171, 0282, 0320, 0321, 0342, 0344, 0346, 0349, 0350	Hyundai	0141
Dual-Tec	0342, 0343	Ferguson	0322, 0345, 0349	Grandin	0340, 0343, 0348, 0349	Iberia	0320
Dumont	0008, 0030, 0062, 0282, 0339, 0341, 0342	Fidelity	0277, 0320, 0342, 0346	Gronic	0282	ICE	0277, 0282, 0320, 0323, 0337, 0340, 0342, 0343, 0350
Durabrand	0031, 0051, 0179, 0215	Filsai	0282	Grundig	0160, 0161, 0171, 0310, 0320	ICeS	0277
Dux	0349	Finlandia	0346			Ilo	0148, 0153
Dwin	0178	Finlux	0171, 0282, 0320, 0339, 0341, 0342, 0349, 0350			IMA	0058
Dynatron	0320, 0349, 0350	FIRST LINE	0342, 0343, 0350			Imperial	0161, 0171, 0320, 0347, 0350, 0351
Dynex	0228, 0231	Firstline	0277, 0282, 0320, 0323			Indiana	0320, 0349, 0350
EIZO	0509	Fisher	0019, 0161, 0282, 0339, 0342, 0344, 0351				
Elbe	0161, 0168, 0282, 0320	Flint	0320, 0350				
		Formenti	0171, 0277, 0336, 0339, 0342, 0349				
		Formenti/Phoenix	0277				
		Fortress	0336, 0339				
		Fraba	0161, 0320				
		Friac	0161				

Infinity	0010	KLH	0039	Magnavox	0008, 0009, 0010, 0013,	Motion	0171
InFocus	0250, 0327, 0363, 0479,	Kloss Novabeam	0057, 0058		0026, 0032, 0033, 0048,	Motorola	0052, 0178
	0508	Kneissel	0161, 0168, 0320		0050, 0128, 0211, 0212,	MTC	0008, 0026, 0050, 0053,
Ingelen	0347	Kolster	0320, 0350		0224, 0226, 0239		0161, 0277
Ingersol	0323, 0343	Konka	0340	Magnum	0337, 0343	Multi System	0349
Initial	0153	Korpel	0320, 0349, 0350	Majestic	0054	Multitech	0058, 0161, 0179, 0183,
Inno Hit	0171, 0282, 0320, 0323,	Korting	0161, 0339	Mandor	0337		0277, 0282, 0320, 0323,
	0340, 0342, 0343, 0349,	Kosmos	0320	Manesth	0282, 0320, 0337, 0342,		0341, 0342, 0343, 0344,
	0350	Koyoda	0343		0349, 0350		0346, 0349
Innovation	0337, 0343	KTV	0007, 0050, 0058, 0179,	Marantz	0008, 0010, 0026, 0050,	Murphy	0277, 0342
Insignia	0131, 0228, 0236, 0238		0183, 0282, 0342		0204, 0320, 0349, 0350	NAD	0026, 0031, 0111
Inteq	0030	Kyoto	0277, 0282	Marelli	0339	Naonis	0346
Interactive	0161	Lasat	0161	Mark	0277, 0282, 0320, 0323,	NEC	0008, 0026, 0050, 0052,
Interbuy	0323, 0343	Lenco	0323, 0343		0349, 0350		0053, 0072, 0103, 0282,
Interfunk	0161, 0320, 0339, 0347,	Lenoir	0323, 0342, 0343	Masuda	0282		0344
	0349, 0350	Leyco	0320, 0337, 0349, 0350	Matsui	0282, 0320, 0323, 0342,	Neckermann	0161, 0282, 0320, 0339,
International	0277	LG	0031, 0053, 0066, 0116,		0343, 0344, 0346, 0349,		0342, 0346, 0349, 0350,
Intervision	0161, 0282, 0320, 0337,		0117, 0140, 0161, 0164,		0350, 0455		0351
	0341, 0342		0175, 0195, 0269, 0277,	Matsushita	0017	NEI	0320, 0349, 0350
Irradio	0171, 0320, 0323, 0340,		0282, 0300, 0309, 0317,	Maxent	0147, 0176	Net-TV	0176
	0343, 0349, 0350		0320, 0323, 0328, 0342,	Mediator	0320, 0349, 0350	Neufunk	0320, 0323
Isukai	0320, 0340		0343, 0346, 0349, 0350,	Medion	0320, 0337, 0343	New Tech	0343, 0350
ITC	0282, 0342		0366, 0368, 0377, 0466,	Megapower	0140	New World	0340
ITS	0277, 0320, 0340, 0348,		0471, 0478	Megatron	0026, 0031	NewTech	0282, 0320, 0323
	0350	LG/GoldStar	0164	MElectronic	0277, 0282, 0320, 0323	Nicamagic	0277, 0342
ITT	0343, 0347	Liesenk	0349	Melvox	0321	Nikkai	0277, 0282, 0320, 0323,
ITV	0320, 0343, 0349	Liesenkotter	0320	Memorex	0019, 0026, 0031, 0053,		0337, 0340, 0342, 0349,
Janeil	0057	Life	0337, 0343		0054, 0137, 0215, 0323,		0350
JBL	0010	Lifetec	0320, 0323, 0337, 0343		0343	Nikko	0026, 0031, 0050
JC Penney	0007, 0008, 0026, 0027,	Lloyds	0323	Memphis	0323, 0343	Noblisko	0171, 0277, 0341, 0342
	0049, 0053, 0056	Loewe	0161, 0168, 0265, 0320,	Mercury	0320, 0323	Nokia	0347
JCB	0055, 0107		0330, 0352	Metz	0339	Norcent	0201
Jensen	0008, 0026	Loewe Opta	0339, 0349, 0350	MGA	0008, 0026, 0031, 0050,	Nordic	0282
JVC	0012, 0014, 0015, 0056,	Logik	0054		0053	Nordmende	0339, 0345, 0347, 0350
	0064, 0065, 0067, 0169,	Luma	0320, 0323, 0346, 0349	Micromaxx	0337, 0343	Nordvision	0349
	0174, 0297, 0314, 0344,	Lumatron	0282, 0320, 0346, 0349,	Microstar	0337, 0343	Novatronik	0320
	0350, 0375		0350	Midland	0007, 0021, 0023, 0027,	Oceanic	0321, 0347
Kaisui	0277, 0282, 0320, 0323,	Lux May	0350		0030, 0056, 0062	Okano	0161, 0320, 0351
	0340, 0342, 0343, 0348	Luxman	0008, 0026	Minerva	0171	Olevia	0102, 0199, 0200, 0207,
Kamosonic	0342	Luxor	0282, 0342, 0346	Minoka	0320, 0350		0222
Kamp	0277, 0342	LXI	0010, 0019, 0021, 0026,	Mintek	0153	ONCEAS	0342
Kapsch	0347		0027, 0031, 0049, 0111	Mitsubishi	0008, 0026, 0031, 0053,	Onwa	0058, 0179
Karcher	0161, 0320, 0342, 0343,	M Electronic	0342, 0343, 0345, 0347,		0066, 0084, 0093, 0098,	Opera	0320
	0349		0349, 0350		0150, 0178, 0289, 0320,	Oppo	0130
Kawasho	0008, 0026, 0055, 0277	MAG	0096		0339, 0344, 0350, 0376	Optimus	0017, 0019
KEC	0179	Magnadyne	0339, 0341, 0349	Mivar	0161, 0168, 0171, 0277,	Optoma	0144
Kendo	0161, 0320, 0341, 0346	Magnafon	0171, 0277, 0341, 0342		0282, 0342	Optonica	0178
Kenwood	0008, 0026, 0050			Monivision	0140	Orbit	0320, 0350
KIC	0282			Montgomery Ward	0054		
Kingsley	0277, 0342						

Orion	0043, 0146, 0283, 0320, 0323, 0328, 0343, 0349, 0350	Phonola	0277, 0320, 0339, 0349, 0350	RCA	0008, 0021, 0024, 0025, 0026, 0027, 0042, 0049, 0052, 0053, 0063, 0136, 0225	Schneider	0282, 0316, 0318, 0320, 0333, 0340, 0342, 0349, 0350, 0382
Orline	0320	Pilot	0007, 0008, 0050	Realistic	0019, 0031, 0050, 0179	Scotch	0026, 0031
Osaki	0282, 0320, 0337, 0340, 0342	Pioneer	0008, 0026, 0094, 0095, 0161, 0320, 0345, 0347, 0349, 0350, 0458, 0480	Recor	0320	Scott	0008, 0012, 0026, 0031, 0058, 0059, 0149, 0179
Oso	0340	Plantron	0320, 0323, 0337, 0350	Redstar	0320	Sears	0008, 0010, 0019, 0021, 0026, 0027, 0031, 0049, 0051, 0059, 0111
Otto Versand	0282, 0320, 0336, 0342, 0344, 0348, 0349, 0350	Playsonic	0282	Reflex	0320	SEG	0277, 0282, 0320, 0323, 0337, 0341, 0342, 0344, 0349, 0382
Pael	0277, 0342	Polaroid	0039, 0142, 0202, 0234	Revox	0161, 0320, 0349, 0350	SEI	0320
Palladium	0161, 0282, 0320, 0342, 0351	Poppy	0323, 0343	Rex	0337, 0346, 0347	SEI-Sinudyne	0339, 0341, 0347
Palsonic	0282	Portland	0007, 0008, 0026, 0053	RFT	0161, 0168, 0339	Seleco	0344, 0346, 0347
Panama	0277, 0282, 0320, 0323, 0337, 0342, 0343	Prandoni-Prince	0171, 0346	Rhapsody	0277	Sencora	0323, 0343
Panasonic	0016, 0017, 0020, 0022, 0023, 0035, 0052, 0056, 0084, 0085, 0133, 0163, 0193, 0284, 0286, 0290, 0292, 0320, 0325, 0347, 0356, 0483	Precision	0282, 0342	R-Line	0320, 0349, 0350	Sentra	0323
Panavision	0320	Prima	0157, 0243, 0323, 0343, 0347	Roadstar	0323, 0337, 0340, 0343	Serino	0277
Pathe Cinema	0161, 0168, 0277, 0321, 0342	Princeton	0140	Robotron	0339	Sharp	0000, 0001, 0002, 0003, 0007, 0008, 0012, 0026, 0060, 0088, 0089, 0091, 0138, 0165, 0170, 0178, 0198, 0229, 0262, 0278, 0279, 0291, 0308, 0312, 0336, 0344, 0354, 0370, 0449, 0450, 0451, 0464, 0474, 0476, 0481
Pausa	0323, 0343	Prism	0023, 0056	Rowa	0277, 0282	Sheng Chia	0178
Penney	0021, 0023, 0031, 0050, 0111	Profex	0323, 0343	Royal Lux	0161	Shogun	0008
Perdio	0277, 0320	Profi-Tronic	0320, 0350	RTF	0339	Siarem	0320, 0339, 0341
Perfekt	0320	Proline	0320, 0350	Runco	0030, 0050, 0062	Sierra	0320, 0350
Philco	0008, 0009, 0010, 0012, 0026, 0050, 0052, 0053, 0161, 0171, 0320, 0339	Proscan	0021, 0027, 0049	Saba	0298, 0322, 0339, 0345, 0347	Siesta	0161
Philharmonic	0282, 0342	Prosonic	0161, 0277, 0282, 0320, 0342, 0349	Saisho	0282, 0323, 0337, 0342, 0343	Signature	0054
Philips	0008, 0009, 0010, 0011, 0012, 0032, 0048, 0049, 0052, 0122, 0128, 0134, 0186, 0187, 0213, 0221, 0224, 0226, 0239, 0256, 0257, 0259, 0261, 0263, 0267, 0280, 0281, 0287, 0296, 0299, 0301, 0303, 0305, 0313, 0319, 0320, 0324, 0333, 0339, 0342, 0349, 0350, 0353, 0357, 0360, 0380, 0383, 0452, 0459, 0460	Protech	0282, 0337, 0341, 0342, 0343, 0349, 0350	Salora	0346, 0347	Silver	0277
Philips Magnavox	0011, 0032, 0033	Proton	0008, 0012, 0026, 0031	Sambers	0171, 0341	Singer	0321, 0339, 0341
Phoenix	0161, 0277, 0320, 0339, 0349, 0350	Protron	0196	Sampo	0007, 0008, 0026, 0050, 0176	Sinudyne	0320, 0339, 0341, 0349
		PROVIEW	0096, 0246	Samsung	0004, 0005, 0006, 0007, 0008, 0012, 0026, 0031, 0036, 0050, 0053, 0076, 0077, 0079, 0114, 0124, 0125, 0126, 0127, 0139, 0161, 0183, 0185, 0190, 0191, 0258, 0264, 0277, 0282, 0320, 0323, 0334, 0337, 0342, 0343, 0349, 0350, 0351, 0373, 0453, 0468	Skantic	0347
		Provision	0320, 0349	Sandra	0277, 0282, 0342	Solavox	0347
		Pulsar	0008, 0030, 0062	Sansui	0043, 0109, 0320, 0350	Sonitron	0161, 0282
		Pye	0256, 0320, 0349, 0350, 0378	Sanyo	0008, 0019, 0068, 0070, 0071, 0099, 0161, 0168, 0223, 0237, 0277, 0282, 0288, 0295, 0323, 0342, 0344, 0369, 0469	Sonoko	0282, 0320, 0323, 0337, 0342, 0343, 0349, 0350
		Pymi	0323, 0343			Sonolor	0321, 0347
		Quandra Vision	0321			Sontec	0161, 0320, 0349, 0350
		Quasar	0017, 0023, 0052, 0056			Sony	0038, 0044, 0045, 0047, 0055, 0090, 0104, 0105, 0107, 0110, 0123, 0184, 0220, 0248, 0249, 0251,
		Quelle	0282, 0320, 0337, 0342, 0349, 0350				
		Questa	0344				
		Radialva	0320				
		RadioShack	0019, 0021, 0031, 0050, 0179, 0320				
		RadioShack/Realistic	0007, 0008, 0012, 0026, 0049, 0058				
		Radiola	0282, 0320, 0349, 0350				
		Radiomarelli	0320, 0339				
		Radiotone	0161, 0320, 0323, 0350	SBR	0320, 0349		
		Rank	0344	Sceptre	0235, 0244		
				Schaub Lorenz	0347		

	0252, 0254, 0326, 0343, 0344, 0371, 0374, 0457, 0475, 0486	Techwood 0008, 0023, 0026, 0056 TEDELEX 0282 Teknika 0007, 0008, 0010, 0012, 0026, 0053, 0054, 0058, 0059, 0179	United 0349 Universum 0161, 0171, 0282, 0320, 0337, 0349, 0350, 0351	Yorx 0340 Zanussi 0282, 0346 Zenith 0008, 0028, 0029, 0030, 0031, 0054, 0061, 0062
Sound & Vision	0340, 0341		Univox 0320	
Soundesign	0008, 0026, 0031, 0058, 0059, 0179	Teleavia 0345	Vector Research 0050	
Soundwave	0320, 0349, 0350	Telecor 0282, 0320	Vestel 0282, 0320, 0346, 0347, 0349, 0350, 0351	
Squareview	0051	Telefunken 0320, 0322, 0345, 0350	Vexa 0320, 0323, 0343, 0349	
SSS	0008, 0058, 0179	Telegazi 0320	Victor 0015, 0344, 0350	
Standard	0282, 0320, 0323, 0340, 0342, 0343, 0350	Telemeister 0320	VIDEOLOGIC 0277	
Starlite	0058, 0179, 0320, 0323, 0349	Telesonic 0320	Videologique 0277, 0282, 0340, 0342	
Stenway	0348	Telestarc 0320	VideoSystem 0320, 0350	
Stern	0346, 0347	Teletech 0320, 0323, 0343, 0349	Videotechnic 0277, 0282	
Strato	0320, 0323	Teleton 0282, 0342	Vidikron 0010	
Stylandia	0282	Televideon 0277	Vidtech 0008, 0026, 0031, 0053	
Sunkai	0343	Televiso 0321	Viewsonic 0176, 0203, 0232, 0364	
Sunstar	0320, 0323	Tensai 0282, 0320, 0323, 0340, 0343, 0350	Viking 0057	
Sunwood	0320, 0323, 0343, 0350	Tesmet 0350	Viore 0148	
Superla	0277, 0282, 0342	Tevion 0337, 0343	Visiola 0277, 0342	
Superscan	0013, 0178	Textet 0277, 0282, 0323, 0342	Vision 0282, 0320, 0350	
SuperTech	0277, 0320, 0323	Thomson 0162, 0188, 0189, 0285, 0320, 0322, 0342, 0345, 0350	Vizio 0008, 0177, 0218, 0242, 0500, 0501, 0502, 0503, 0506	
Supra	0323, 0343	Thorn 0320, 0349	Vortec 0320, 0349, 0350	
Supre-Macy	0057	TMK 0008, 0026, 0031	Voxson 0171, 0320, 0339, 0346, 0347, 0350	
Supreme	0055, 0107	TNCi 0030	Waltham 0282, 0320, 0342	
Susumu	0340	Tokai 0282, 0320, 0350	Wards 0008, 0009, 0010, 0026, 0031, 0048, 0049, 0050, 0053, 0054, 0059	
Sutron	0323, 0343	Tokyo 0277, 0342	Watson 0320, 0349, 0350	
SVA	0151	Tomashi 0348	Watt Radio 0277, 0341, 0342	
Sydney	0277, 0282, 0342	Toshiba 0018, 0019, 0040, 0041, 0046, 0073, 0100, 0103, 0108, 0109, 0111, 0121, 0132, 0166, 0208, 0210, 0214, 0217, 0260, 0268, 0282, 0283, 0293, 0304, 0306, 0307, 0329, 0344, 0355, 0454	Waycon 0111	
Sylvania	0008, 0009, 0010, 0011, 0013, 0026, 0048, 0050, 0051, 0128, 0227, 0253	Totevision 0007	Wega 0320, 0339, 0344	
Symphonic	0051, 0058, 0062, 0128, 0179, 0215	Towada 0282, 0347	Wegavox 0323	
Syntax	0199	Trakton 0282	Weltblick 0282, 0320, 0349, 0350	
Syntax-Brilliant	0199	Trans Continens 0282, 0320	Westinghouse 0107, 0216, 0220	
Sysline	0349	Transtec 0277	White Westinghouse	
Sytong	0277	Trident 0282	0037, 0090, 0277, 0320, 0341, 0342, 0349	
Tandy	0178, 0282, 0336, 0340, 0342, 0347	Triumph 0320	Wincom 0101, 0106	
Tashiko	0277, 0282, 0342, 0344, 0346	Uher 0161, 0171, 0320, 0347, 0350	Xrypton 0320	
Tatung	0052, 0177, 0282, 0320, 0342, 0349, 0350	Ultravox 0277, 0320, 0339, 0341, 0342	Yamaha 0008, 0026, 0050, 0053, 0080, 0081, 0082, 0083, 0086, 0087	
TCM	0337, 0343	Unic Line 0320	Yamishi 0282, 0320	
Teac	0282, 0320		Yokan 0320	
Tec	0282, 0323, 0342, 0343		Yoko 0161, 0277, 0282, 0320, 0323, 0337, 0340, 0342, 0343, 0349, 0350	
Technics	0017, 0023, 0056			
TechniSat	0274, 0496, 0497, 0499			

VCR

ABS	1016
Adventura	1069
Adyson	1008
Aiwa	1024, 1026, 1027, 1069
Akai	1021, 1027
Akiba	1008, 1029
Akura	1008, 1027, 1029
Alba	1008, 1009, 1024, 1025, 1029, 1030
Alienware	1016
Ambassador	1030
American High	1068
Amstrad	1008, 1009, 1026
Anitech	1008, 1029
Apex	1088
ASA	1028, 1031
Asha	1070
Asuka	1008, 1026, 1028, 1029, 1031
Audio Dynamics	1064
Audiosonic	1009
Audiovox	1071
Baird	1009, 1025, 1026, 1027
Bang & Olufsen	1017
Basic Line	1008, 1009, 1024, 1025, 1029, 1030
Baur	1028
Beaumark	1070
Bell & Howell	1065
Bestar	1009, 1025, 1030
Black Panther Line	
	1009, 1025
Blaupunkt	1028
Bondstec	1008, 1030
Broksonic	1100
Bush	1008, 1009, 1024, 1025, 1029, 1049, 1051, 1063, 1217
Calix	1071
Candle	1070, 1071
Canon	1068
Cathay	1009

Catron	1030	Firstline	1008, 1024, 1029, 1031	iBUYPOWER	1016	Matsushita	1068
CGE	1026, 1027	Fisher	1065	Impego	1030	Media Center PC	1016
Cimeline	1008, 1024, 1029	Flint	1024	Imperial	1026	Mediator	1028
CineVision	1104	Formenti/Phoenix	1028	Inno Hit	1008, 1009, 1025, 1028, 1029, 1030	Medion	1024
Citizen	1070, 1071	Frontech	1030			MEI	1068
Clatronic	1008, 1030	Fuji	1068	Innovation	1024	Memorex	1023, 1026, 1031, 1065, 1068, 1069, 1070, 1071, 1098, 1114
Colortyme	1064	Fujitsu	1026	Instant Replay	1068		
Condor	1009, 1025, 1030	Funai	1026, 1069	Interbuy	1008, 1031	Memphis	1008, 1029
Craig	1070, 1071	Galaxy	1026	Interfunk	1028	MGN Technology	1070
Crown	1008, 1009, 1025, 1029, 1030	Garrard	1069	Intervision	1009, 1026	Micromaxx	1024
		Gateway	1016	Irradio	1008, 1029, 1031	Microsoft	1016
Curtis Mathes	1064, 1068, 1070	GBC	1029, 1030	ITT	1027	Microstar	1024
Cybernex	1070	GE	1068, 1070	ITV	1009, 1025, 1031	Migros	1026
CyberPower	1016	GEC	1028	JC Penney	1064, 1065, 1068, 1070, 1071	Mind	1016
Daewoo	1009, 1025, 1030, 1038, 1069, 1223	Geloso	1029	JCL	1068	Mitsubishi	1026, 1028, 1079
		General	1030	JVC	1007, 1018, 1027, 1039, 1064, 1065, 1066, 1067, 1078, 1089, 1092, 1093, 1094, 1095, 1113, 1208, 1209, 1212, 1213, 1215, 1218	Motorola	1068
Dansai	1008, 1009, 1029	General Technic	1024			MTC	1070
Dantax	1024	GOI	1018			Multitech	1008, 1026, 1028, 1029, 1030, 1069, 1070
Daytron	1009, 1025	GoldHand	1008, 1029				
DBX	1064	Goldstar	1026, 1031, 1064, 1071			Murphy	1026
De Graaf	1028	Goodmans	1008, 1009, 1025, 1026, 1029, 1030, 1031			NEC	1027, 1064, 1065
Decca	1026, 1027, 1028			Kaisui	1008, 1029	Neckermann	1027, 1028
Dell	1016	Gradiente	1069	Karcher	1028	NEI	1028
Denko	1008	Graetz	1027	Kendo	1008, 1024, 1025, 1030	Nesco	1008, 1029
DiamondVision	1096	Granada	1028	Kenwood	1027, 1064, 1065	Nikkai	1008, 1009, 1030
DigiFusion	1014	Grandin	1008, 1009, 1025, 1026, 1029, 1030, 1031	Kodak	1068, 1071	Nikko	1071
DIRECTV	1019, 1105, 1110, 1111, 1113, 1116, 1122	Grundig	1028, 1029	Korpel	1008, 1029	Niveus Media	1016
		Hanseatic	1009, 1028, 1031	Kyoto	1008	Noblex	1070
Dish Network	1018	Harley Davidson	1069	Lenco	1025	Nokia	1009, 1027
Dishpro	1018	Harman/Kardon	1064	Leyco	1008, 1029	Nordmende	1027
Dual	1009, 1027, 1028	Harwood	1008	LG	1010, 1026, 1031, 1047, 1054, 1056, 1071, 1103, 1221	Northgate	1016
Dumont	1026, 1028	HCM	1008, 1029			Oceanic	1026, 1027
Durabrand	1114	Headquarter	1065			Okano	1008, 1009, 1024
Dynatech	1069	Hewlett Packard	1016	Lifetec	1024	Olympus	1068
Echostar	1018	Hinari	1008, 1009, 1024, 1029	Linksys	1016	Optimus	1071
Elbe	1009	Hisawa	1024	Lloyd's	1069	Orion	1023, 1024, 1051, 1115, 1217
Elcatech	1008	Hitachi	1011, 1026, 1027, 1028, 1046, 1062	Loewe Opta	1028, 1031		
Electrohome	1071			Logik	1008, 1029	Orson	1026
Electrohome	1071	HNS	1110	Lumatron	1009, 1025	Osaki	1008, 1026, 1029, 1031
Elsay	1008	Howard Computers	1016	Luxor	1008	Otto Versand	1028
Elta	1008, 1009, 1029			LXI	1071	Palladium	1008, 1027, 1029, 1031
Emerson	1008, 1020, 1068, 1069, 1071	HP	1016	M Electronic	1026	Panasonic	1000, 1022, 1044, 1055, 1068, 1072, 1085, 1090, 1091, 1120, 1121, 1214
		HTS	1018	Magnavox	1020, 1068, 1114, 1126		
ESC	1009, 1025	Hughes	1111, 1113, 1122	Magnin	1071		
Etzuko	1008, 1029	Hughes Network Systems	1110, 1116	Manesth	1008, 1029	Pathe Marconi	1027
Expressvu	1018			Marantz	1028, 1064, 1065, 1068	Perdio	1026
Ferguson	1027	Humax	1012, 1110, 1113	Mark	1009	Philco	1008, 1068
Fidelity	1008, 1026	Hush	1016	Marta	1071		
Finlandia	1028	Hypson	1008, 1009, 1024, 1029	Matsui	1024, 1031		
Finlux	1026, 1027, 1028						

Philips	1006, 1013, 1028, 1035, 1040, 1045, 1046, 1050, 1058, 1059, 1061, 1068, 1076, 1101, 1110, 1113, 1116, 1117, 1122, 1126, 1210, 1211	Sanky	1114	Tandberg	1009	Zenith	1114
Philips Magnavox	1076	Sansui	1023, 1027, 1106, 1115	Tandy	1065	ZT Group	1016
Phonola	1028	Sanyo	1032, 1065, 1070	Tashiko	1026, 1071		
Pilot	1071	Saville	1009	Tatung	1026, 1027, 1028		
Pioneer	1028, 1036	SBR	1028	TCM	1015, 1024, 1042		
Polaroid	1088, 1099	Schaub Lorenz	1026, 1027	Teac	1009, 1069		
Portland	1009, 1025, 1030	Schneider	1008, 1009, 1024, 1025, 1026, 1028, 1029, 1030, 1031	Tec	1008, 1009, 1030		
Prinz	1026			Technics	1068		
Profex	1029	Sears	1065, 1068, 1071	Teknika	1068, 1069, 1071		
Proline	1026	SEG	1008, 1009, 1029	Teleavia	1027		
Proscan	1019	SEI-Sinudyne	1028	Telefunken	1027		
Prosonic	1009, 1024	Seleco	1027	Teletech	1008, 1009		
Pulsar	1114	Sentra	1008, 1030	Tenosal	1008, 1029		
Pye	1028, 1102	Sentron	1008, 1029	Tensai	1008, 1026, 1029, 1031		
Quarter	1065	Sharp	1003, 1033, 1077, 1107, 1127, 1219	Tevion	1024		
Quartz	1065	Shintom	1008, 1029	Thomson	1005, 1027		
Quasar	1068	Shivaki	1031	Thorn	1027		
Quelle	1026, 1028	Shogun	1070	Tivo	1108, 1110, 1111, 1113, 1117, 1118, 1119, 1122		
Radialva	1008	Siemens	1031	TMK	1070		
RadioShack	1071	Silva	1031	Tokai	1008, 1029, 1031		
RadioShack/Realistic	1065, 1068, 1069, 1070, 1071	Silver	1009	Tonsai	1029		
Radiola	1028	Singer	1068	Toshiba	1004, 1016, 1027, 1028, 1037, 1049, 1052, 1086, 1087, 1097, 1109, 1112, 1194		
Radix	1071	Sinudyne	1028				
Randex	1071	Solavox	1030	Totevision	1070, 1071		
RCA	1019, 1068, 1070, 1075, 1110, 1113, 1122, 1125	Sonic Blue	1022, 1123	Touch	1016		
Realistic	1065, 1068, 1069, 1070, 1071	Sonneclair	1008	Towada	1008, 1029		
ReplayTV	1022, 1123	Sonoko	1009, 1025	Towika	1008, 1029		
Rex	1027	Sontec	1031	TVA	1030		
RFT	1008, 1028, 1030	Sony	1001, 1016, 1048, 1053, 1073, 1074, 1080, 1081, 1082, 1083, 1108, 1118, 1216	Uher	1031		
Ricavision	1016			UltimateTV	1019		
Roadstar	1008, 1009, 1025, 1029, 1031	Stack	1016	Ultravox	1009		
Royal	1008	Stack 9	1016	Unitech	1070		
Runco	1114	Standard	1009, 1025	United Quick Star	1009, 1025		
Saba	1027	Stern	1009	Universum	1026, 1028, 1031		
Saisho	1024, 1029	STS	1068	Vector Research	1064		
Samsung	1002, 1034, 1041, 1043, 1057, 1060, 1070, 1084, 1110, 1116, 1122, 1124, 1220, 1222	Sunkai	1024	Video Concepts	1064		
Samurai	1008, 1030	Sunstar	1026	Videon	1024		
		Suntronc	1026	Videosonic	1070		
		Sunwood	1008, 1029	Viewsonic	1016		
		Superscan	1020	Voodoo	1016		
		Sylvania	1020, 1068, 1069, 1102, 1126	Wards	1068, 1069, 1070, 1071		
				Weltblick	1031		
		Symphonic	1008, 1069, 1126	XR-1000	1068, 1069		
		Systemax	1016	Yamaha	1064, 1065		
		Tagar Systems	1016	Yamishi	1008, 1029		
		Taisho	1024	Yokan	1008, 1029		
				Yoko	1008, 1029, 1030, 1031		

DVD

4Kus	2051
Accurian	2142
Advent	2155, 2251
AEG	2362
Airis	2364
Aiwa	2322
Akai	2145, 2177, 2179, 2248
Akura	2356
Alba	2064, 2165, 2186, 2337, 2346
Alco	2149
Alize	2361
Allegro	2133
Amitech	2362
Amphion MediaWorks	2195
AMW	2195, 2363
Apex	2030, 2124, 2125, 2126, 2127, 2130, 2131
Apple	2241
Arrgo	2138
Asono	2364
Aspire	2152, 2222
Astar	2240
ATACOM	2364
Audiovox	2061, 2149
Avious	2367
Awa	2363
Axion	2249
Bang & Olufsen	2128
Baze	2367
BBK	2364
Bellagio	2363
Best Buy	2359
Blaupunkt	2131
Blue Parade	2157
Boghe	2382
Brainwave	2362
Brandt	2148, 2188
Broksonic	2145, 2146
Bush	2064, 2110, 2170, 2268, 2290, 2346, 2358, 2367, 2383

California Audio Labs		Elta	2341, 2361, 2362	2260, 2262, 2263, 2321,	Minowa	2367
2151		Emerson	2129, 2137, 2150	2324, 2326, 2327, 2343,	Mintek	2131, 2245
Cambridge Audio	2354	Enterprise	2129	2464, 2465, 2468, 2469,	Mitsubishi	2003
CAT	2352, 2353	Enzer	2380	2471, 2511	Mizuda	2358, 2359
CAVS	2192	Epson	2247	Jwin	Monyka	2380
Centrum	2353	ESA	2137	Kansai	Mustek	2186
CGV	2354, 2362	Finlux	2354, 2362, 2367	Kawasaki	Mx Onda	2354
Changhong	2140	Fintec	2377	Kennex	Mystral	2366
Cinetec	2363	Fisher	2134	Kenwood	Naiko	2362
CineVision	2133, 2237	Funai	2137	KeyPlug	Nesa	2131
Clatronic	2358, 2367	Gateway	2051	Kiuro	Neufunk	2380
Coby	2031, 2046, 2360	GE	2029, 2131, 2156	Kingavon	Nevir	2362
Conia	2383	Gericom	2351	Kiss	Next Base	2143
Continental Edison		GFM	2226	KLH	Nexstech	2243
2363		Giec	2382	Koda	NU-TEC	2383
Crown	2362	Global Solutions	2355	Koss	Onkyo	2159, 2368
C-Tech	2355	Global Sphere	2355	KXD	Oopla	2051
Curtis Mathes	2139	Go Video	2133, 2213	Landel	Oppo	2196, 2255
CVG	2377	Goodmans	2165, 2280, 2291, 2358,	Lasonic	Optim	2381
CyberHome	2022, 2098, 2138, 2187,		2371, 2376, 2382	Lawson	Optimus	2180
	2336	GPX	2227	Lecson	Orava	2358
Cytron	2244	Gradiente	2151	Lenco	Orbit	2363
Daenyx	2363	Graetz	2380	Lenoxx	Orion	2073, 2110
Daewoo	2001, 2133, 2276, 2298,	Greenhill	2131	LG	Oritron	2148, 2158
	2330, 2362, 2363, 2377	Grundig	2349		P&B	2358
Daewoo International		Grunkel	2362, 2366		Pacific	2355
2363		GVG	2377		Panasonic	2011, 2024, 2034, 2042,
Dalton	2357	H&B	2358	Life		2058, 2062, 2066, 2067,
Dansai	2362, 2381	H_her	2364	Lifetec		2093, 2116, 2117, 2118,
Daytek	2184, 2195, 2363	Haaz	2354, 2355	Limit		2119, 2120, 2121, 2122,
Dayton	2363	Haier	2254	Liquid Video		2123, 2151, 2159, 2164,
DEC	2358	Harman/Kardon	2047, 2135	Liteon		2166, 2167, 2172, 2173,
Decca	2362	HiMAX	2359	Loewe		2175, 2209, 2214, 2275,
Denon	2059, 2151, 2193, 2332	Hitachi	2062, 2090, 2115, 2274,	LogicLab		2277, 2278, 2281, 2282,
Denver	2356, 2358, 2360, 2370		2282, 2316, 2359, 2380	Magnavox		2283, 2301, 2374, 2470
Denzel	2380	Hiteker	2130		Parasound	2197
Desay	2205	Home Tech Industries			peekKTON	2364
Diamond	2354, 2355		2364	Magnex	Philips	2008, 2012, 2025, 2044,
DiamondVision	2225, 2232	Hyundai	2366	Majestic		2050, 2051, 2053, 2060,
Disney	2010, 2028	Ilo	2245	Marantz		2072, 2108, 2111, 2147,
DK Digital	2339	Initial	2131, 2245	Marquant		2159, 2163, 2169, 2174,
Dmtech	2176	Innovation	2182	Matsui		2181, 2185, 2230, 2261,
Dual	2380	Insignia	2002, 2137, 2253	McIntosh		2266, 2267, 2286, 2287,
Durabrand	2136	Integra	2157	Mecotek		2289, 2295, 2300, 2302,
DVX	2355	Irradio	2053	Medion		2317, 2328, 2338, 2342,
Easy Home	2359	iSymphony	2246	Memorex		2350, 2467
Eclipse	2354	JBL	2135	MiCO		
E-Dem	2364	JVC	2020, 2096, 2097, 2099,	Micromaxx	Phonotrend	2367
Electrohome	2362		2100, 2101, 2102, 2103,	Microsoft	Pioneer	2016, 2017, 2018, 2019,
Elin	2362		2106, 2107, 2160, 2257,	Microstar		2035, 2092, 2094, 2095,
				Minoka		2109, 2157, 2180, 2190,

	2212, 2269, 2272, 2299, 2304, 2305, 2306, 2307, 2308, 2309, 2310, 2311, 2344, 2345, 2347, 2379	Sharp	2006, 2040, 2088, 2091, 2182, 2194, 2220, 2221, 2231, 2236, 2293, 2340	Top Success	2364	Panasonic	2011, 2209, 2214, 2476, 2477, 2479
Pointer	2362	Shinonic	2245	Toshiba	2032, 2036, 2037, 2039, 2048, 2049, 2054, 2055, 2072, 2073, 2076, 2078, 2079, 2086, 2145, 2159, 2218, 2233, 2256, 2259, 2296, 2369	Philips	2510
Polaroid	2125, 2215, 2235	Sigmathek	2359, 2364	TRANScontinents	2363, 2367	Pioneer	2212, 2506
Portland	2362	Silva	2356	Transonic	2367	Samsung	2045, 2113, 2498
Powerpoint	2363	Singer	2354, 2355	Trio	2362	Sharp	2194, 2220, 2221, 2497, 2502, 2503
Prima	2252	Skymaster	2325, 2355	Trutech	2242	Sony	2075, 2453, 2458, 2459, 2507
Proceed	2130	Skyworth	2356	TruVision	2359	Toshiba	2462
Proscan	2156	Slim Art	2362	TSM	2364	Yamaha	2064, 2448, 2449, 2474, 2505
Prosonic	2360, 2377	SM Electronic	2355	Umax	2361		
Protron	2202	Sonic Blue	2133	United	2367		
Provision	2358	Sontech	2366	Urban Concepts	2159	DVR	
Pye	2144	Sony	2004, 2005, 2007, 2009, 2014, 2015, 2023, 2026, 2027, 2052, 2068, 2069, 2070, 2071, 2074, 2075, 2084, 2085, 2087, 2168, 2171, 2208, 2210, 2211, 2258, 2273, 2284, 2285, 2312, 2313, 2314, 2315, 2318, 2319, 2466	US Logic	2245	Bush	2110
Qwestar	2148			Venturer	2149	Hitachi	2090
Raite	2380			Viewmaster	2364	Panasonic	2066, 2067, 2093, 2116, 2117, 2119, 2120, 2122, 2123
RCA	2021, 2029, 2104, 2105, 2131, 2149, 2156, 2157, 2229	Soundmaster	2355	Vocopro	2206	Philips	2108, 2111
RedStar	2356, 2360, 2362	Soundmax	2355	VocoStar	2207	Pioneer	2016, 2017, 2018, 2019, 2092, 2094, 2095, 2109
Regent	2153	Spectra	2363	Waitec	2364	RCA	2105
Reoc	2355	Spectroniq	2201	Welltech	2382	Samsung	2113, 2219
Rimax	2361	Standard	2355	Westinghouse	2063, 2250	Sharp	2088, 2091
Rio	2133	Star Cluster	2355	Wharfedale	2354, 2355	Sony	2084, 2085, 2087
Roadstar	2331, 2358	Starmedia	2358, 2364	Woxter	2361, 2364	Toshiba	2086
Ronin	2363	Sungale	2204	Xbox	2156, 2183	Victor	2475
Rotel	2203	Sunkai	2362	Xlogic	2355, 2362	Yamaha	2089, 2118
Rowa	2154, 2383	Superscan	2150	XMS	2362		
Rownsonic	2353	Supervision	2355	Xoro	2382		
Saba	2148, 2188	Sylvania	2012, 2137, 2150, 2178, 2230, 2239	Yamada	2051, 2361, 2363		
Sabaki	2355			Yamaha	2056, 2064, 2065, 2080, 2081, 2082, 2083, 2089, 2118, 2151, 2323		
Saivod	2362	Symphonic	2108, 2230	Yamakawa	2363, 2380		
Sampo	2141	Synn	2355	Yukai	2186		
Samsung	2000, 2045, 2077, 2112, 2113, 2114, 2115, 2151, 2200, 2216, 2219, 2228, 2264, 2265, 2271, 2279, 2294, 2303, 2329, 2365	T.D.E. Systems	2366	Zenith	2002, 2129, 2133, 2159, 2223		
Sansui	2073, 2145, 2354, 2355, 2362	Tatung	2001, 2362			DVD Recorder	
Sanyo	2134, 2145, 2217, 2292	TCM	2182, 2297			Aspire	2222
ScanMagic	2186	Teac	2149, 2333, 2355, 2383			Astar	2240
Schaub Lorenz	2362	Tec	2356			Broksonic	2146
Schneider	2176	Technics	2151			Go Video	2213
Scientific Labs	2355	Technika	2362, 2367			Hitachi	2062
Scott	2161, 2357	Telefunken	2353			Insignia	2002
Seeltech	2364	Tensai	2362			Irradio	2053
SEG	2162, 2355, 2363, 2380	Tevion	2182, 2355, 2357			JVC	2100, 2101, 2106, 2107
		Theta Digital	2157			LG	2033, 2057, 2223, 2238
		Thomson	2183, 2188, 2334, 2372			Liteon	2043
		Tokai	2356, 2380			Panasonic	2011, 2034, 2058, 2062, 2116, 2117, 2119, 2120, 2121, 2123
				Blu-ray Disc		Philips	2008, 2044, 2050, 2051, 2147
				Denon	2452, 2500, 2501	Pioneer	2017, 2035
				Hitachi	2460, 2461, 2463		
				JVC	2472, 2473, 2478, 2496, 2499, 2511		
				LG	2033, 2456, 2457		
				Marantz	2454, 2455		
				Mitsubishi	2450, 2451		
				Onkyo	2504		

Pye 2144
 Samsung 2000, 2112, 2216
 Sansui 2073
 Sanyo 2217
 Sony 2004, 2005, 2007, 2052,
 2068, 2069, 2074, 2208,
 2210, 2211
 Sylvania 2239
 Toshiba 2032, 2036, 2037, 2039,
 2049, 2054, 2055, 2076
 Yamaha 2056

Cable

ABC 3002, 3003, 3017, 3066,
 3067, 3086, 3093, 3119,
 3122
 ADB 3020
 Adelphia 3081
 Alcatel 3016
 Americast 3124
 Amstrad 3022, 3098
 Antronix 3065, 3070
 Archer 3070
 Arcon 3098
 AT&T 3095
 Axis 3098
 Bell South 3124
 Cable Vision 3092
 Cabletenna 3065
 Cabletime 3104
 Cableview 3087
 Clearmaster 3127
 ClearMax 3127
 Clyde Cablevision 3105
 Colour Voice 3068
 Comcast 3084, 3088, 3117
 Comcrypt 3107
 Comtronics 3069
 Contec 3074
 Coolmax 3127
 COX 3084
 Cryptovision 3110
 Director 3084
 Eastern 3075
 Everquest 3123
 Fidelity 3098
 Filmnet 3107

Filmnet Cablecrypt
 3111
 Filmnet Comcrypt
 3111
 Finlux 3097
 Focus 3126
 Foxtel 3022
 France Telecom 3100, 3101
 Freebox 3023
 GC Electronics 3070
 GE 3066, 3093
 GEC 3105
 Gemini 3072, 3123
 General Instrument
 3017, 3025, 3066, 3084,
 3090, 3096, 3117
 Goldstar 3120
 Gooding 3099
 Grundig 3098, 3099
 Hamlin 3073, 3078
 Hirschmann 3097
 Hitachi 3066
 HomeChoice 3106
 Humax 3021, 3080, 3083
 ITT Nokia 3097
 Jasco 3123
 Jerrold 3017, 3018, 3025, 3066,
 3072, 3084, 3090, 3096,
 3119, 3123
 JVC 3099
 Kabel Deutschland
 3024, 3027, 3121
 Macab 3101
 Magnavox 3079
 Maspro 3099
 Matsui 3099
 MegaCable 3117
 Memorex 3076, 3122
 Minerva 3099
 Mnet 3107
 Motorola 3025, 3026, 3084, 3088,
 3090, 3095, 3117
 Movie Time 3077, 3109
 Mr Zapp 3101
 Multichoice 3107
 Multitech 3127
 NEC 3064
 NET Brazil 3085
 Nokia 3097
 Noos 3101

NSC 3077
 Oak 3074
 Pace 3006, 3089, 3121
 Palladium 3099
 Panasonic 3112, 3118, 3122
 Paragon 3122
 Philips 3068, 3071, 3079, 3099,
 3100, 3101, 3103
 Pioneer 3001, 3006, 3094, 3098,
 3114, 3116, 3120
 Popular Mechanics
 3126
 Proscan 3066, 3093
 Pulsar 3122
 PVP Stereo Visual Matrix
 3018
 Quasar 3122
 RadioShack 3123, 3127
 RCA 3030, 3031, 3087, 3118
 Realistic 3070
 Recoton 3126
 Regal 3078
 Regency 3075
 Rembrandt 3066
 Runco 3122
 Sagem 3101
 Samsung 3069, 3089, 3114, 3120
 SAT 3098
 Scientific Atlanta 3000, 3001, 3002, 3003,
 3006, 3028, 3029, 3081,
 3086, 3089, 3094, 3095,
 3108
 Signal 3072, 3123
 Signature 3066
 Sony 3092, 3125
 Sprucer 3118
 Standard Component
 3115
 Starcom 3017, 3072, 3119, 3123
 Stargate 3072, 3123
 Starquest 3072, 3123
 Supercable 3090
 Supermax 3127
 Tele+1 3107, 3111
 Telepiu 3107
 Thomson 3082, 3091
 TIME WARNER 3084
 Tocom 3067
 Torx 3017
 Toshiba 3122

Tristar 3127
 Tudi 3102
 Tusa 3072, 3123
 TV86 3077
 Unika 3065, 3070
 United Cable 3018, 3119
 Universal 3065, 3070
 Universum 3097, 3099
 V2 3127
 Verizon Fios 3007
 Videoway 3019
 View Star 3074, 3077, 3079
 Viewmaster 3127
 Vision 3127
 Visiopass 3097, 3100, 3101
 Vortex View 3127
 Wittenberg 3098
 Zenith 3113, 3122, 3124
 Zentek 3126

Satellite

AB Sat 4216, 4217
 AccessHD 4104
 ADB 4220
 AGS 4216
 Akai 4053, 4055
 Alba 4001, 4004, 4006, 4007,
 4062, 4217
 Aldes 4005, 4007, 4010
 Allsat 4048, 4053, 4055
 Allsonic 4005, 4008, 4024
 Alltech 4217
 Alpha 4053
 Alpha Digital 4104
 Alphastar 4077
 Amitronica 4217
 Amstrad 4011, 4035, 4217, 4218
 Anglo 4217
 Ankaro 4005, 4008, 4024, 4217
 Anttron 4001, 4004
 Apollo 4001
 Armstrong 4011, 4053
 Artec 4100
 Asat 4053, 4055
 ASLF 4217
 Astacom 4216
 Astra 4009, 4011, 4054, 4217,
 4219

Astro	4004, 4008, 4010, 4015, 4024, 4213, 4218, 4219	Digital Stream	4105	FinnSat	4050, 4052	Intervision	4048, 4219
AudioTon	4004, 4048	DIRECTV	4056, 4064, 4067, 4068, 4070, 4071, 4074, 4107, 4116, 4119, 4121, 4122, 4123, 4127, 4192, 4193, 4194, 4195, 4196, 4197, 4198, 4199, 4200, 4201, 4202, 4203, 4206, 4207, 4221	Flair Mate	4217	ITT Nokia	4006
Aurora	4222	Discoverer	4212	Foxtel	4222	Jerrold	4019
Austar	4222	Discovery	4216	Freecom	4001, 4049, 4218	Johansson	4013
Axiel	4216	Diseqc	4216	FTEmaximal	4024, 4217	JOK	4216
Axis	4008, 4009, 4024, 4050	Dish Network	4018, 4065, 4089, 4092, 4094, 4095, 4117	Fuba	4001, 4008, 4014, 4015, 4024, 4055, 4215	JSR	4048
Best	4008, 4024	Dishpro	4018, 4117	Galaxis	4005, 4008, 4009, 4024, 4048, 4050, 4215, 4222	JVC	4029, 4065, 4089, 4117
Blaupunkt	4015	Distrisat	4053	GE	4066, 4093, 4111, 4197	Kamm	4217
Blue Sky	4217	Ditristrad	4048	General Instrument		Kathrein	4015, 4034, 4042, 4053, 4055, 4063, 4215, 4216, 4217
Boca	4011, 4054, 4059, 4217	DNT	4014, 4053, 4055		4019, 4073	Kathrein Eurostar	4215
Boston	4216	Drake	4072	GMI	4011	Klap	4216
Brain Wave	4013	DStv	4222	GOI	4117	Konig	4219
Broadcast	4012	Dune	4024	Goldbox	4213	Kosmos	4049
Broco	4217	Echostar	4014, 4018, 4065, 4089, 4117, 4217	GoldStar	4049	KR	4004
BSkyB	4035, 4041	Einhell	4001, 4005, 4011, 4217, 4218	Goodmans	4002, 4006, 4029	Kreiselmeier	4015
BT	4216	Elap	4216, 4217	Goodmind	4111	K-SAT	4217
Bubu Sat	4217	Elekta	4010	Grandin	4031	Kyostar	4001
Bush	4006, 4045	Elsat	4217	Grothusen	4001, 4049	L&S Electronic	4024
Cambridge	4218	Elta	4001, 4008, 4024, 4048, 4053, 4055	Grundig	4004, 4006, 4015, 4035, 4211, 4218, 4222	Lasat	4008, 4010, 4024, 4054, 4212, 4215, 4219
Canal Satellite	4213	Emanon	4001	Hänsel & Gretel	4219	Lasonic	4108
Canal+	4213	Emme Esse	4008, 4024	Hantor	4001, 4013	Lenco	4001, 4024, 4049, 4215, 4217, 4219
CaptiveWorks	4099	Engel	4217	Hanuri	4010	Leng	4013
Channel Master	4007, 4110	Ep Sat	4006	Hauppauge	4044	Lennox	4048
Chaparral	4075	EURIEULT	4031	Heliocom	4219	Lenson	4218
CHEROKEE	4216	Eurodec	4052	Helium	4219	Lexus	4053
Chess	4212, 4217	Europa	4053, 4218, 4219	Hinari	4007	LG	4049, 4103, 4107
CityCom	4006, 4215, 4219	Europhon	4219	Hirschmann	4015, 4024, 4210, 4216, 4218, 4219	Lifesat	4008, 4024, 4212, 4217
Clatronic	4013	Eurosat	4011	Hisawa	4013	Lifetec	4008
CNT	4010	Eurosky	4008, 4011, 4024, 4215, 4218, 4219	Hisense	4016	Lorenzen	4219
Comag	4080, 4081, 4082, 4083, 4086	Eutelsat	4011, 4215, 4219	Hitachi	4006, 4114, 4199, 4203	Lorraine	4049
Commlink	4005	Exator	4001, 4004	Homecast	4084, 4085, 4087	Lupus	4008, 4024
Comtech	4050	Expressvu	4117	Houston	4048	Luxor	4218
Condor	4008, 4024, 4219	Fenner	4024, 4212, 4217	HTS	4117	Lyonnaise	4052
Connexions	4014, 4024	Ferguson	4006, 4052, 4214	Hughes	4064, 4068, 4192, 4194, 4196, 4202	Macab	4052
Conrad	4024, 4215, 4218, 4219	Fidelity	4218	Hughes Network Systems		Magnavox	4101, 4127
Conrad Electronic	4217, 4219	Finlandia	4006		4071	Manata	4031, 4216, 4217
Contec	4050	Finlux	4006	Humax	4025, 4030, 4060, 4097	Manhattan	4006, 4010, 4048, 4216
Coolsat	4096			Huth	4005, 4011, 4012, 4013, 4048, 4050, 4219, 4223	Marantz	4055
Cosat	4048			Hypson	4031	Mascom	4010
Coship	4109			Ilo	4016	Maspro	4006, 4217
Crown	4011			Imex	4031	Matsui	4216
Daeryung	4014			Innovation	4008	Max	4219
Daewoo	4057, 4217			Insignia	4107	Mediabox	4213
DDC	4007			Intertronic	4011	Mediamarkt	4011
Delega	4007					Mediasat	4009, 4213, 4218
Dew	4050					Medion	4008, 4024, 4217
Diamond	4051						
Digiality	4219						

Medison	4217	Panasonic	4006, 4035, 4036, 4121, 4124, 4126, 4198, 4221	Samsung	4000, 4001, 4003, 4032, 4064, 4069, 4071, 4120, 4123, 4196, 4200	Tandy	4004
Mega	4053, 4055					Tantec	4006
Memorex	4127	Panda	4006, 4219	SAT	4007, 4218	TCM	4008
Metronic	4001, 4004, 4005, 4010, 4028, 4031, 4217	Pansat	4125	Sat Cruiser	4223	Techniland	4012
Metz	4015	Patriot	4216	Sat Partner	4001, 4004, 4010, 4013, 4049, 4218	TechniSat	4014, 4021, 4026, 4027, 4038, 4039, 4053, 4212, 4213, 4218
Micro electronic	4217, 4218, 4219	Paysat	4127	Sat Team	4217	Technology	4222
Micro Technology	4217	PCT	4110	Satcom	4012, 4219	Technosat	4223
MicroGem	4106	Philco	4101	Satec	4217	Technowelt	4219
Micromaxx	4008, 4024	Philips	4006, 4033, 4053, 4055, 4061, 4068, 4071, 4127, 4196, 4201, 4202, 4203, 4206, 4213, 4216	Satelco	4024	Teco	4011, 4054
Microstar	4008			Satford	4012	Telanor	4007
Microtec	4217	Phoenix	4050	Satmaster	4012	Telasat	4215, 4219
Minerva	4015	Phonotrend	4005, 4006, 4048	Satplus	4212	Telecom	4217
Mitsubishi	4006, 4015, 4202	Pioneer	4046, 4213	Schneider	4008, 4212, 4216	Telefunken	4001, 4017, 4216
Mitsumi	4054	Polsat	4052	Schwaiger	4051, 4212, 4219	Teleka	4004, 4011, 4014, 4218, 4219
Morgan's	4011, 4053, 4054, 4055, 4217	Predki	4013	SCS	4215	Telemaster	4010
Motorola	4019, 4088, 4090, 4091	Premiere	4048, 4213	Seemann	4009, 4011, 4014	Telesat	4219
Multichoice	4222	Priesner	4011	SEG	4001, 4008, 4013, 4024	Telestar	4212, 4213, 4218
Multitec	4212	Primestar	4076	Seleco	4048	Televés	4006, 4218
Muratto	4049	Profile	4216	Servi Sat	4031, 4217	Telewire	4048
Mysat	4217	Promax	4006	Siemens	4015	Tempo	4223
Navex	4013	Prosat	4005, 4007	Silva	4049	Tevion	4008, 4217
Neuhaus	4009, 4048, 4217, 4218, 4219	Proscan	4066, 4093, 4122, 4197	Skantin	4217	Thomson	4006, 4020, 4052, 4058, 4208, 4213, 4215, 4216, 4217, 4219
Neusat	4217	Protek	4051	Skardin	4009	Thorens	4051
Next Level	4019	Proton	4016	Skinsat	4218	Thorn	4006
NextWave	4223	Provision	4010	SKR	4217	Tivax	4104
Nikko	4011, 4217	Quadral	4005, 4007, 4008, 4024, 4216	Skymaster	4005, 4017, 4022, 4212, 4217	Tivo	4196
Nokia	4006, 4040	Quelle	4015, 4215, 4219	Skymax	4053, 4055	Tokai	4053
Nordmende	4001, 4006, 4007, 4010, 4052	Quiero	4052	SkySat	4212, 4217, 4218, 4219	Tonna	4006, 4012, 4048, 4217, 4218
Nova	4222	RadioShack	4019	Skyvision	4048	Toshiba	4194, 4202, 4203
Novis	4013	Radiola	4053, 4055	SM Electronic	4212, 4217	Triad	4049
Oceanic	4051	Radix	4014, 4037	Smart	4215, 4217	Triasat	4218
Octagon	4001, 4004, 4050	Rainbow	4004	Sony	4067, 4070, 4213	Triax	4015, 4215, 4217, 4218
Okano	4011	RCA	4066, 4093, 4112, 4113, 4116, 4118, 4119, 4122, 4197, 4207	SR	4011, 4054	Turnsat	4217
Optex	4048			Star Choice	4019	Tvonics	4214
Optus	4213, 4222, 4223	Realistic	4078	Starland	4217	Twinner	4031, 4217
Orbitech	4001, 4212, 4213, 4218	Redpoint	4009	Starring	4013	UEC	4222
OSat	4004	Redstar	4008, 4024	Start Trak	4001	Uher	4212
Otto Versand	4015	RFT	4005, 4053, 4055	Strong	4001, 4004, 4008, 4024, 4049, 4222	UltimateTV	4070
Pace	4006, 4015, 4035, 4043, 4047, 4216	Roadstar	4217	STS	4115	Uniden	4079, 4127
Pacific	4051	Roch	4031	STVI	4031	Unisat	4011, 4050, 4053
Packsat	4216	Rover	4024, 4217	Sumida	4011	Unitor	4013
Palcom	4007	Saba	4010, 4215, 4216, 4219	Sunny Sound	4024	Universum	4015, 4215, 4219
Palladium	4011, 4218	Sabre	4006	Sunsat	4217	US Digital	4016
Palsat	4212, 4218	Sagem	4023, 4052	Sunstar	4011, 4024, 4054	Variosat	4015
Panasat	4222	Sakura	4050	Supermax	4223		
				Tandberg	4052		

Vega	4024
Ventana	4053, 4055
Viewsat	4098
Visiosat	4013, 4048, 4216, 4217
Voom	4019
Vortec	4001
Welltech	4212
WeTeKom	4212, 4218
Wevasat	4006
Wewa	4006
Winersat	4013
Wisi	4006, 4014, 4015, 4218, 4219
Woorisat	4010
Worldsat	4216
Xrypton	4024
XSat	4217
Zehnder	4008, 4010, 4024, 4209, 4215
Zenith	4102, 4107, 4195
Zodiac	4004

CD

Yamaha 5082, 5095

CD Recorder

Yamaha 5083

MD

Yamaha 5080, 5081, 5086

Tape

Yamaha 5084, 5087

Tuner

Yamaha 5066, 5085, 5088, 5090,
5092

XM

Yamaha 5091, 5093

SIRIUS

Yamaha 5064, 5067

DOCK

Yamaha 5068, 5089

NET

Yamaha 5071, 5076, 5079, 5094

LD

Yamaha 2080

Amplifier

Yamaha 5019, 5020, 5098

Apple TV

Apple 2241

“Apple TV” is a trademark or registered mark of Apple Inc.